## **MAGNESIUM L-LACTATE**

Prepared at the 27th JECFA (1983), published in FNP 28 (1983) and in FNP 52 (1992). Metals and arsenic specifications revised at the 63rd JECFA (2004). An ADI 'not limited' was established at the 23rd JECFA (1979)

**SYNONYMS** L-Lactic acid magnesium salt, magnesium di-L-lactate, INS No. 329

**DEFINITION** 

Chemical names Magnesium L(-)-2-hydroxypropionate dihydrate

C.A.S. number 18917-93-6

Chemical formula  $Mg(C_3H_5O_3)_2 \cdot 2H_2O$ 

Structural formula

Formula weight 238.48

Assay Not less than 97.5% and not more than 101.5% on the dried basis

**DESCRIPTION** White crystalline powder

FUNCTIONAL USES Buffering agent, dough conditioner, dietary supplement

## **CHARACTERISTICS**

**IDENTIFICATION** 

Solubility (Vol. 4) Soluble in water when shaking with water for 30 min; practically insoluble in

ethanol

Specific rotation (Vol. 4) [alpha] 25, D: -7.5 to -8.8 (5% w/v aqueous solution)

Test for magnesium

(Vol. 4)

Passes test

Test for lactate (Vol. 4) Passes test

**PURITY** 

Loss on drying (Vol. 4) 14.0 - 17.0% (120°, 24 h)

Chlorides (Vol. 4) Not more than 0.01%

Test 1 g of the sample as directed in the Limit Test using 0.3 ml of 0.01 N

hydrochloric acid in the control

Microbiological criteria

(Vol. 4)

Total aerobic microbial count: Max 1000/g

Total yeast and moulds: Max 100/g

E. coli: Absent in 1 g

Lead (Vol. 4)

Not more than 2 mg/kg

Determine using an atomic absorption technique appropriate to the specified level. The selection of sample size and method of sample preparation may be based on the principles of the method described in

Volume 4, "Instrumental Methods."

METHOD OF ASSAY

Dissolve about 0.5 g of the dried sample, accurately weighed, in 25 ml of water, add 5 ml of ammonia/ammonium chloride buffer TS and 0.1 ml of ethylenediaminetetraacetate until the solution is blue in colour. Each ml of 0.05 M disodium ethylenediaminetetraacetate is equivalent to 10.12 mg of

 $Mg(C_3H_5O_3)_2$ .